

INSTALLATION INSTRUCTIONS

1474 - TO SUIT MAZDA MPV V6
PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN

WARNING : 1. Do not drill, cut weld or otherwise modify the towbar.
2. If you are using electric welding on a motor vehicle, always check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could destroy any onboard computers. If in doubt, check with the vehicle's manufacturer.

1. Ensure all hardware items have been included.
2. Remove bumper and cut sections of bumper out as per diagram.
3. Remove spare wheel.
4. Lift towbar into position and fit two bolts on each side.
5. Using towbar as a guide drill two lower holes on vehicle out to 11mm and fit bolts, plates, nuts and washers as per diagram.
6. Refit bumper making sure bumper studs go through towbar.
7. Tighten all bolts to torque listing below.
8. Refit spare wheel.
9. Towbar rating sticker to be conspicuously located on inside rear end of the driver's door. (see diagram below)

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 4.6 Bolt</u>	<u>Grade 8.8 Bolt</u>
	Nm	Nm
M6	3.5	9.5
M8	8.6	21.7
M10	16.9	43.4
M12	29.8	77.3
M16	74.0	189.8

PLEASE NOTE: You must remove the lug unless you are actually towing if it obscures your number plate. Failure to do so may result in a fine.
IMPORTANT: Please see over for safety chain hook-up procedure.

1474 - TO SUIT MAZDA MPV V6

