

Fitting Instructions: BYD01

Vehicle:	BYD SEALION 6
Towing Capacity:	1300/150KGS
Fitting Kit:	4 – 12 x 40 wire to bolts & flange nuts 2 – 12 x 40 flange bolts\ 2 – 12mm tapped plates 4 – 16mm flat washers (to be used as spacers) 1 – dee shackle

1.	Remove internal floor boot floor cover & tray
2.	Remove both boot side trims.
3.	Remove rear wheel arch trims
4.	Remove rear bumper bar (taillights do not require removal)
5.	Feed bolts on wire into rear subframe and align with original holes in base of sub frame that align with towbar side arm holes (2 wire to bolts either side)
6.	Fit (4) flat washers supplied between wire to bolts fitted & sub frame (as per picture below), then mount towbar via bolts (Flat washers are spacer) fit nuts & tighten
7.	Drill remaining 2 holes, 1 either side rear sub frame to accept 12mm bolts, fit tapped plates into sub frame, align with drilled holes, fit bolts & tighten
8.	Trim excess wire from bolts on wire then refit crash support panel.
9.	Refit rear bumper bar, wheel trims & all boot trims
10.	Apply towbar rating labels to driver side door sill & non removable section of towbar

