

Fitting Instructions: BYD02H

Vehicle: BYD SEALION 7

Towing Capacity: RWD 75 / 750Kg
AWD 150 / 1500KGS

Fitting Kit: 2 – Dee Shackles
2 – Rating labels

SMART ECM03 REQUIRED

1.	Remove rear wheel arch plastic flares.
2.	Remove rear bumper bar from vehicle. (Ensure all factory bumper wiring is disconnected) (Taillights are not required to be removed to complete this process).
3.	Remove and discard factory crash support panel, Remove sensor which will be reposition to Towbar bracket. (Retain factory bolts and nuts)
4.	Fit towbar using the factory bolts and nuts from crash support panel. (Tighten once centred).
5.	Refit sensor removed to towbar bracket.
6.	Re-fit rear bumper bar making sure all factory wiring is reconnected. Remove factory bumper centre cover plate to access tow hitch.
7.	Apply towbar rating labels to driver side door sill & non removable section of towbar.