

Fitting Instructions: BYD02

Vehicle: BYD SEALION 5

Towing Capacity: 750/75KGS

Fitting Kit: 6 – 1 ¼ x 3/8 bolts on wire (Grind 3 sides) nuts, flats & stars
1 – Dee shackle

ECM01S Required

1.	Remove bumper plate from centre of bumper.
2.	Remove rubber grommets from passenger and driver side base of chassis.
3.	Fit towbar into position aligning with original holes in chassis, both side and base.
4.	Feed bolts on wire supplied into chassis align with holes, three either side. Fit flat, star then nuts.
5.	Tighten all bolts.
6.	Apply towbar rating labels to driver side door sill & non removable section of towbar.

Wiring Code

Tail	Drivers side – red yellow
Stop	Drivers side – red white
Earth	Body
Right	Drivers side – purple red
left	Passengers side – yellow red