

Fitting Instructions: BYD03H

Vehicle: BYD SEALION 8

Towing Capacity: FWD 200 / 1800Kg
AWD 200 / 2000KGS

Fitting Kit: 2 – Dee Shackles
2 – Rating labels

SMART ECM03 REQUIRED

1.	Remove rear wheel arch plastic flares.
2.	Remove rear bumper bar from vehicle. (Ensure all factory bumper wiring is disconnected) (Taillights are not required to be removed to complete this process).
3.	Remove and discard factory crash support panel. (Retain factory bolts and nuts)
4.	Fit towbar using the factory bolts and nuts from crash support panel. (Tighten once centred).
5.	<u>Bumper cut is required on this vehicle.</u> Find centre of bumper at base, measure 45mm either side of centre and mark. Measure 125mm upwards of bumper and mark. (Cut once finalised)
6.	Re-fit rear bumper bar once bumper cut is complete making sure all factory wiring is reconnected.
7.	Apply towbar rating labels to driver side door sill & non removable section of towbar.

ECM Wiring Code

WIRING IS LOCATED UNDER TAILLIGHTS BOTH LEFT AND RIGHT SIDE

Tail	GREEN WIRE (RIGHTSIDE)
Stop	BLUE & RED (RIGHTSIDE)
Earth	BODY
Right	YELLOW (RIGHTSIDE)
left	YELLOW & GREEN (LEFTSIDE)