

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

CHR43/52 FITTING INSTRUCTIONS
(CHR 43 MAGNA TR – TS) – (CHR 52 TE -)

REMOVE SPARE WHEEL
REMOVE REAR TIE DOWN BRACKETS & DISCARD.
REMOVE REAR EXHAUST BRACKET.
MOUNT TOWBAR TO EXISTING HOLES IN REAR CHASSIS USING 10mm
BOLTS SUPPLIED THEN TIGHTEN.
DRILL (10mm) TWO HOLES INTO SPARE WHEEL CARRYING AREA VIA
FORWARD TOWBAR ARMS, FIT BOLTS WITH PLATES THEN SPRING
WASHERS & NUTS – TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.
REFIT SPARE WHEEL.

FITTING KIT

4 – 10 x 35mm FINE THREAD BOLTS, SPRING & FLAT WASHERS
2 – 11/4 x 3/8 BOLTS, NUTS SPRING & FLAT WASHERS.
2 – 10mm HOLE PLATES
1 – DEE SHACKLE