



Towbar Fitting Instructions  
To Suit  
MITSUBISHI CG LANCER SEDAN 8-02-ON  
Part Number CL77  
Rating 1000Kg

1. Ensure all hardware items have been included.
2. Remove plastic trim button from underside of bumper in centre if required.
3. Lift towbar into position then align holes in side plates with captive nuts in sub frame.
4. Fit bolts spring & flat washers supplied as per drawing
5. Tighten all bolts to torque listing below.
6. Refit plastic trim button if required.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8



Towbar Fitting Instructions  
To Suit  
MITSUBISHI CG LANCER SEDAN 8-02-ON  
Part Number CL77  
Rating 1000Kg

