

**BORONIA TOWBARS P/L**  
**1/12 EDINA RD**  
**FERNTREE GULLY**  
**VIC 3156**  
**PH: (03) 9752 2642**  
**FAX: (03) 9752 2575**

**DAT72 FITTING INSTRUCTIONS**  
**PULSAR VECTOR N13**  
**TOWING CAPACITY 800KG**

REMOVE TIE DOWN HOOKS AND DISCARD.  
FIT TOWBAR UP TO CHASSIS USING BOLTS SUPPLIED. FIT EXHAUST TO  
BRACKET OFF TOWBAR.  
REMOVE SPARE WHEEL, DRILL TWO HOLES VIA TOWBAR INTO SPARE  
WHEEL AREA.  
FIT PLATES, BOLTS, NUTS, SPRING & FLAT WASHERS. TIGHTEN.  
CHECK ALL BOLTS FOR TIGHTNESS.

**FITTING KIT:**

4 - 10mm x 35mm FINE THREAD BOLTS. SPRING & FLAT WASHER.  
2 - 1.1/2" X 3/8" BOLTS.NUTS.SPRING WASHERS.  
1 - 8mm NUTS. & SPRING WASHERS.  
2 - 3" X 1.1/2" X 3/8" PLATES.  
1 - D. SHACKLE.