

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

DAT75 / DAT76 FITTING INSTRUCTIONS
NISSAN PINTARA SEDAN V12
TOWING CAPACITY 900KG

REMOVE TOWING HOOKS.
PLACE TOWBAR UP TO VEHICLE.
FIT (10mm) BOLTS SUPPLIED & SPRING & FLAT WASHERS TO ALL
CORRESPONDING HOLES.
DRILL (10mm) REMAINING HOLE VIA TOWBAR AND FIT WIRE TO BOLT
INTO CHASSIS AND DOWN THROUGH TOWBAR.
TIGHTEN ALL BOLTS.

FITTING KIT:

6 - 10mm x 35mm FINE THREAD BOLTS. SPRING & FLAT WASHERS.
1 - 1.1/2" 3/8" BOLT.
1 - 3/8" NUT ON WIRE. SPRING & FLAT WASHERS.
1 - D SHACKLE.