

## Fitting Instructions: FOR067 / FOR013H / FOR013FH

|                         |                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Vehicle:</b>         | BA-FG Falcon Sedan / Fairlane                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Towing Capacity:</b> | FOR067 - 1600kg, <b>FOR013H / FOR013FH - 2300kg Hitch Receiver</b>                                                                                                                                                                                                                                                                                                                                |
| <b>Fitting Kit:</b>     | <p>4x Self drill bolts (10mm) &amp; flat washers</p> <p>1x 16mm nut on wire</p> <p>1x 16 x 35 bolt &amp; spring &amp; flat washer</p> <p>1x D shackle</p> <p><b>2x 10mm tapped plates on wire</b></p> <p><b>2x 10 x 35mm fine bolts, star &amp; flat washer</b></p> <p><b>2x 1¼ x ¾ bolts, nuts, star &amp; flat washers</b></p> <p><b>2x 10mm hole plates</b></p> <p>2x Towbar Rating Labels</p> |

### Additional kit for Fairlane (FOR013FH):

|    |                                                  |
|----|--------------------------------------------------|
| 1x | <b>10 x 45 fine bolt, star &amp; flat washer</b> |
| 1x | <b>Spacer block 12mm (TOY014H)</b>               |

**Note: Bold print = FOR13H / FOR013FH only**

|    |                                                                                                                                                                                                                                                                                                                                                                                                        |
|----|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Remove rear bumper bar <i>(on FG models, remove tail lights)</i> .                                                                                                                                                                                                                                                                                                                                     |
| 2. | Mount towbar to rear panel using four (4) self drilling bolts, two on each side. Tighten self drilling bolts on passenger side of car first before tightening the self drilling bolts on drivers side.                                                                                                                                                                                                 |
| 3. | Fit 16mm bolt complete with wire to nut & spring washer through centre support. Tighten.                                                                                                                                                                                                                                                                                                               |
| 4. | <p><b><u>Additional Hitch fitting instructions:</u></b></p> <p>In addition to above fitting the hitch requires one (1) 1¼ x ¾ bolt on wire with star &amp; flat washer to be fitted via drilled 10mm hole - forward arm – passenger side sub frame, then drill (10mm) hole via forward arm drivers side into sub frame, fit tapped plate complete with 10mm bolt, star &amp; flat washer supplied.</p> |
| 5. | Fit remaining two bolts, complete with plates, via original holes in cross chassis then through towbar centre uprights, fit nuts, spring and flat washers.                                                                                                                                                                                                                                             |
| 6. | Tighten all bolts.                                                                                                                                                                                                                                                                                                                                                                                     |
| 7. | <p><b><u>Fairlane:</u></b></p> <p>Fit towbar / hitch as above. Cut off plastic guide pin in centre of bumper (cut flush to bumper). Fit spacer block supplied to drivers side forward arm, fit long bolt provided, tighten.</p>                                                                                                                                                                        |
| 8. | <p>Refit rear bumper bar.</p> <p>Note: On FG models only - bumper cut required as per template marked on inside of bumper.</p>                                                                                                                                                                                                                                                                         |
| 9. | Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.                                                                                                                                                                                                                                                                                                     |