

**BORONIA TOWBARS P/L**  
**1/12 EDINA RD**  
**FERNTREE GULLY**  
**VIC 3156**  
**PH: (03) 9752 2642**  
**FAX: (03) 9752 2575**

**FOR14H FITTING INSTRUCTIONS**  
**MAVERICK & PATROL UTE 1988 - ON**  
**TOWING CAPACITY 2800KG**

MOUNT TOWHITCH TO CENTRE MOUNT VIA EXISTING (4) HOLES USING 12mm x 30mm BOLTS, SPRING & FLAT WASHERS SUPPLIED.  
FIT TWO CENTRE BOLTS ON WIRE TO CROSS MEMBER EXISTING HOLES. THEN THROUGH CENTRE (2) UPRIGHTS, FIT NUTS COMPLETE WITH SPRING WASHERS." FEED LONG WIRE TO BOLT INTO CHASSIS, FIT VIA EXISTING FORWARD HOLE & THROUGH TOW HITCH SIDE ARM, FIT SPRING WASHERS & NUTS, TIGHTEN.  
DRILL (1/2") REMAINING TWO HOLES VIA TOW HITCH SIDE ARMS & FIT 1/2" BOLTS WITH PLATES SUPPLIED, FIT SPRING WASHERS & NUTS THEN TIGHTEN.  
TIGHTEN ALL BOLTS.

**FITTING KIT:**

- 2 - 1.1/4" x 3/8" BOLTS ON WIRE, NUTS & SPRING WASHERS.
- 4 - 12mm x 30mm BOLTS, SPRING & FLAT WASHERS.
- 2 - 2" x 1/2" BOLTS ON LONG WIRE, NUTS, SPRING & FLAT WASHERS.
- 2 - 2" x 1/2" BOLTS, NUTS, SPRING & FLAT WASHERS.
- 2 - 12mm HOLE PLATES.
- 2 - D SHACKLES.