



Fitting Instructions: FOT01H

Vehicle: Foton Tunland V7 (2025 – ON)

Towing Capacity: 3500 / 350 kg's

Fitting Kit includes:

- 14x 12 x 1.25 x 40 flange bolts
- 2x 12 x 1.25 x 40 wire to bolts
- 12x 12mm fine flange nuts
- 2x Towbar Rating Labels

1.	Mount Side arms to chassis using factory mounting holes with supplied 12mm flange bolts
2.	Fit Wire to bolts inside chassis rails, one either side of the chassis rail. Aligning with holes in side arms (do not tighten at this stage).
3.	Mount cross pipe using supplied 12mm bolts and nuts (do not tighten at this stage).
4.	Tighten side arm bolts FIRST, then tighten cross pipe bolts.
5.	Check all bolts for tightness.
6.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.