

Fitting Instructions: GW06H

Vehicle: Great wall cannon Alpha

Towing Capacity: 3500kg/350kg

Fitting Kit:

1 - 13 to 7 pin adaptor

6 - 14 x 120 bolts, nuts, star & flat washers

2 – 8mm nuts & star washers

2 – D shackles

1.	Remove all bumper holding bolts (8).
2.	Remove 13 pin plug bracket from vehicle.
3.	Mount tow hitch using original 14 x 40 bolts (1 either side).
4.	Fit remaining 14mm bolts supplied (14 x 120).
5.	Tighten all bolts.
6.	Refit 13 pin plug bracket to mounting plate on bar using original bolts & 2 x 8mm nuts supplied.
7.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.