



Fitting Instructions: GW07H

- Vehicle:** GWM CANNON ALPHA (PHEV) UTE
- Towing Capacity:** 3500 / 350 kg's
- Fitting Kit includes:**
- 8x 12 x 1.25 x 40 Flange bolts and nuts
 - 2x 8mm nuts
 - 2x D-Shackles
 - 2x Towbar Rating Labels
 - 1 x 13 to 7 pin adaptor

1.	Remove original 14mm nuts from chassis (4 either side), (Note, nuts are extremely tight, try undoing at bolt head side rather than nut side). Retain nuts.
2.	Remove 13pin plug bracket from centre sub frame passenger side.
3.	Fit Towbar sidearms using original 14 mm nuts. Do not tighten at this stage.
4.	Fit Towbar cross pipe using 12mm Flange bolts and nuts supplied.
5.	Tighten side arm bolts / nuts.
6.	Tighten cross pipe bolts / nuts.
7.	Refit 13 pin plug bracket to towbar plate passenger side of cross pipe using original bolts and 8mm nuts supplied.
8.	Recheck all bolts for tightness.
9.	13 – 7pin adaptor supplied with kit must not be fitted to vehicle when <u>not</u> towing.
10.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.