

**Fitting
Instructions:** **HAV05H**

Vehicle: Haval Jolion HEV Hybrid Wagon 02-2021 On

Towing Capacity 1500Kgs / 150Kgs (Towball Load)

- Fitting Kit:**
- 4 – 14 x 1.5 x 35mm **Medium** thread bolts, stars and flat washers
 - 2 – 1 1/2 x 3/8 Bolts on wire (No washers) nuts, stars & flat washers
 - 2 – Dee shackles
 - 2 – Towbar rating labels

*****ECM 01 Required*****

1.	<p>Bumper Cut required prior to installation</p> <p>Locate centre of bumper and mark 45mm either side of centre. Mark 135mm up from edge of base of bumper. Cut out this section and discard.</p>
2.	<p>Mount Tow hitch via existing holes which align with Towbar holes using 14mm bolts. Once fitted then tighten these bolts.</p>
3.	<p>Drill 10mm holes via rear most hole in Tow hitch side arm. (1 either side)</p>
4.	<p>Remove boot mat and spare wheel surround panelling. Remove rubber grommet (1 either side). Fit wire to bolt via hole in boot floor and align with pre drilled 10mm hole. Complete with flat, star washers and nut via undercar. Tighten</p>
5.	<p>Check all bolts for tightness and refit boot panelling, spare wheel surround and mat.</p>
6.	<p>Replace rear bumper once towbar is finalised. (Small corrections with bumper cut may be required prior to fitting)</p>
7.	<p>Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.</p>