

**Fitting
Instructions:** **HAV06H**

Vehicle: Haval H7 HEV 2025 – On

Towing Capacity 1500Kgs / 75Kgs (Towball Load)

Fitting Kit: 4 – 12mm course thread nuts, stars and flat washers

2 – Dee shackles

2 – Towbar rating labels

*** ECM 01 Required***

1.	Remove passenger side exhaust rubber and centre exhaust rubber to allow muffler to drop.
2.	Mount Tow hitch via existing studs which align with Towbar holes using 12mm course nut star and flat washers supplied. Tighten.
3.	Refit exhaust rubbers removed in step 1.
7.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.