

Fitting Instructions: **HOL044**

Vehicle:	Holden Monaro Coupe (2002 – on)
Towing Capacity:	1200kg
Fitting Kit:	2x 1¼ x ¾ bolts, nuts, spring & flat washers
	2x 10mm hole plates
	1x 'D' Shackle
	2x Towbar Rating Labels

1.	Remove rear bumper sensor lead from inside boot.
2.	Remove rear bumper bar.
3.	Remove spare wheel.
4.	Remove crash support panel and discard.
5.	Mount towbar to rear panel via studs, fit nuts & tighten.
6.	Drill (10mm) two hole via towbar undercar into boot area, fit bolts supplied complete with plates, spring washers & nuts. Tighten.
7.	Check all bolts for tightness.
8.	Refit rear bumper bar & sensor lead.
9.	Refit spare wheel.
10.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.