

BORONIA TOWBARS P/L
1/12 EDINA RD .
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

HOL52 / HOL21H FITTING INSTRUCTIONS
VE COMMODORE UTE

REMOVE TUB LINER.
REMOVE REAR BUMPER (AFTER REMOVING MUD FLAPS & PLASTIC PLUGS, BUMPER IS HELD BY PRESS INS. PULL SIDE OF BUMPER AWAY FROM BODY, THEN FIRMLY PULL BUMPER FROM REAR OF CAR)
CUT SECTION OUT OF BUMPER (AS PER TEMPLATE LOCATED INSIDE BUMPER), FILE AND NEATEN EDGES AFTER SECTION IS CUT OUT.
REMOVE BOTH REAR MUFFLERS.
REMOVE BOTTOM TAILGATE HINGE BOLTS, ONE EITHER SIDE.
MOUNT TOWBAR USING HINGE BOLTS, CENTRALIZE & LIGHTLY TIGHTEN.
DRILL OUT (1 ½" DRILL) BOTTOM HOLES IN REAR CHASSIS WHICH ALIGN WITH TOWBAR SIDE ARM HOLES.
FIT ½ " BOLTS SUPPLIED VIA PLATES THEN FIT CRUSH TUBES.
FIT VIA EXISTING HOLES IN FLOOR OF CARGO AREA DOWN THROUGH CHASSIS & TOWBAR SIDE ARMS.
FIT NUTS WITH SPRING & FLAT WASHERS - TIGHTEN.
TIGHTEN TAILGATE HINGE BOLTS.
REFIT MUFFLERS, BUMPER BAR & TUB LINER.

FITTING KIT: HOL52 / 21H

4 – 6 x ½" BOLTS, NUTS, SPRING & FLAT WASHERS.
4 – 89mm CRUSH TUBES
2 – TWO HOLE PLATES
1 – DEE SHACKLE. (2 - HITCH)

**ORIGINAL EQUIPMENT ELECTRONIC CONTROL MODULE MUST BE
INSTALLED WHEN WIRING THIS VEHICLE
REFER MANUFACTURERS INSTRUCTIONS**