

Fitting Instructions:

HOL056

Vehicle: Holden CRUZE Wagon 2014 - ON

Towing Capacity: 1200kg / 90kg

Fitting Kit:

- 2x 1½ x 3/8 Bolts, Nuts, Flat & Star Washers
- 2x M12 x 40 Bolts, Flat & Star Washers
- 2x 10mm Hole Plates (trimmed on long edge)
- 1x 'D' Shackle
- 2x Towbar Rating Labels

1.	Remove tail lights
2.	Remove bumper
3.	Remove & discard crash support panel. Retain nuts removed as these are required for the towbar installation.
4.	Mount towbar to rear of car, forward arms insert into chassis & align with studs on rear panel.
5.	Secure towbar to rear of car using nuts removed in step 3 but do not tighten at this stage.
6.	Feed 12mm bolt via star, flat washers to underside of car aligning with existing holes & tapped holes in towbar. Do not tighten at this stage.
7.	Ensure towbar is located central & tighten all nuts on back panel (4), then underside of car (2).
8.	Drill via towbar remaining holes in back panel (2).
9.	Feed 3/8 bolts via 10mm trimmed hole plates from underside of car via holes drilled in step 8. Fit flat, star washers & nuts. Tighten.
10.	Replace bumper & tail lights.
11.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.