

BTA Towing Equipment

Australia's Towing Equipment Specialist



Fitting Instructions: HYU012H

Vehicle: Hyundai Santa Fe WAGON 2024 – on

REMOVE SPARE WHEEL.

REMOVE REAR BUMPER BAR COMPLETE WITH CRASH SUPPORT PANEL.

REMOVE CENTRE SENSOR SITUATED IN THE CENTRE OF CRASH SUPPORT PANEL ON SOME MODELS (SENSOR TO BE REFITTED TO TOW HITCH ONCE INSTALLED).

REMOVE CRASH SUPPORT PANEL AND DISCARD.

BUMPER CUT REQUIRED, FIND CENTRE OF BUMPER BAR.

MEASURE 40MM EITHER SIDE OF CENTRE CUT RECTANGULAR SECTION AS PER PICTURE BELOW (Cut up to ribbed stepped section, **no higher**).

MOUNT TOWBAR USING 4 – 12 X 40MM BOLTS COMPLETE WITH NUTS VIA EXISTING HOLES IN BACK PANEL. DO NOT TIGHTEN AT THIS STAGE.

FIT 1 – 12 X 30MM BOLT COMPLETE WITH STAR AND FLAT WASHER VIA PASSENGER SIDE SUPPORT ARM UNDER CAR WHICH WILL ALIGN WITH EXISTING THREADED HOLE IN CHASSIS. DO NOT TIGHTEN AT THIS STAGE.

FIT REMAINING 2 – 12 X MM BOLTS COMPLETE WITH STAR AND FLAT WASHERS VIA DRIVERS SIDE SUPPORT ARM WHICH WILL ALIGN WITH EXISTING THREADED HOLES IN CHASSIS.

TIGHTEN ALL BOLTS.

FIT SENSOR TO CENTRE TOW HITCH BRACKET & FIT ORIGINAL SCREWS.

REFIT REAR BUMPER BAR. DRILL (8MM) 2 HOLES ALIGNING WITH TABS MOUNTED EITHER SIDE OF HITCH BOX, USE 2 PLASTIC HOLDING CLIPS REMOVED FROM CRASH SUPPORT PANEL TO FASTEN BUMPER TO TABS.

REFIT SPARE WHEEL.

FITTING KIT: ECM01 REQUIRED

6 – 12 x 1.25 X 40MM FINE FLANGE BOLTS.

1 – 12 X 30MM FINE THREAD BOLT, STAR AND FLAT WASHERS.

4 – 12MM FLANGE NUTS

2 - DEE SHACKLES

