

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**HYU1H FITTING INSTRUCTIONS
TERRACAN 4WD**

MOUNT TOWHITCH TO VEHICLES' OUTER REAR CHASSIS THROUGH EXISTING HOLES USING ½" BOLTS SUPPLIED, FIT PLATES & NUTS COMPLETE WITH FLAT & SPRING WASHERS – TIGHTEN.
FIT 12mm BOLTS SUPPLIED WITH PLATES VIA EXISTING HOLES IN CHASSIS WHICH WILL ALIGN WITH TOWHITCH, FIT NUTS COMPLETE WITH SPRING & FLAT WASHERS – TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

4 – 5/16 x ½ BOLTS, NUTS, SPRING & FLAT WASHERS.
2 – 12 x 40mm BOLTS, NUTS, SPRING & FLAT WASHERS.
6 – 12mm HOLE PLATES.
2 – DEE SHACKLES.