



Fitting Instructions: HYU026

Vehicle: HYUNDAI i30 Hatch 04/2017 - ON

Towing Capacity: 1200kg

Fitting Kit:

4x	M10 x 1.25 x 35 Bolts, Flat & Spring Washers
1x	1 1/4 x 3/8 Bolt, nuts & Spring Washer
1x	10mm Hole Plate
1x	M8 Nut only
1x	S Bend bracket
1x	D shackle
2x	Towbar Rating Labels

1.	Remove Spare Wheel.
2.	Undercar - remove plastic guards adjacent to chassis rails to allow full access to side of chassis.
3.	Undercar - remove exhaust rubbers on front and rear of muffler & exhaust rubber allowing exhaust to drop away from car. (On models with charcoal canister located passenger side rear chassis, remove canister from rear most retaining bolt).
4.	Bumper cut required prior to fitting towbar. Locate centre of bumper, cut 40mm each side of centre & up 35mm from edge of bumper. Cut is not visible.
5.	Feed towbar in behind rear bumper align side arms with original holes in chassis. Mount towbar using M10 bolts complete with spring / flat washers (2 each side). Tighten all bolts,
6.	Drill (10mm) hole via centre towbar plate into spare wheel area in boot, fit plate complete with 1 1/4 x 3/8 bolt, fit nut with spring washer under car and tighten.
7.	Refit canister using 8mm bolt via original stud in base of chassis complete with S Bend bracket (canister will fit between towbar side arm and spare wheel well).
8.	Replace plastic guards removed in step 1.
9.	Refit spare wheel.
10.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.