

Fitting Instructions: JAC01H

Vehicle: JAC T9 UTE

Towing Capacity: 3200 / 320Kgs

Fitting Kit includes:

- 14X 12 X 40 Fine Flange bolts
- 8x 12mm Fine Flange Nuts
- 2x Dee Shackles
- 2x Rating labels

1.	Mount Left and right-side arms to both sides of chassis rails using the original holes in chassis rails (3 either side) of the base of chassis using supplied 12mm flange bolts and nuts. (Do not tighten at this stage).
2.	Mount cross pipe to both driver and passenger side arms using supplied 12mm flange bolts and nuts, 4 either side.
3.	Lightly tighten side arm flange bolts connecting to chassis rails.
4.	Tighten cross pipe bolts
5.	Centralise towbar to vehicle and tighten side arm bolts.
6.	Apply rating label stickers to both driver door area and non-removable part of towbar.