

BTA Towbars

Australia's Towing Equipment Specialist



Fitting Instructions: JEEP02H

Vehicle:	Jeep Wrangler (1996 – 2007)
Towing Capacity:	900kg
Fitting Kit:	2x 12 x 40mm bolts, nuts, spring & flat washers
	2x 4 x ½ bolts, nuts, spring & flat washers
	2x ½" hole plates
	2x 'D' shackles
	2x Towbar Rating Labels

	<i>Note: Tow hitch will not fit vehicles fitted with chrome pipe rear bumper. This is a Jeep optional extra).</i>
1.	Remove rear tie downs & discard.
2.	Mount tow hitch to rear sub frame using tie down holding bolts, fit 12mm bolt supplied to remaining hole. Tighten.
3.	Fit remaining bolts via tow hitch and sub frame fit plates spring & flat washers, nuts then tighten.
4.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.