

BTA Towbars

Australia's Towing Equipment Specialist



Fitting Instructions: KIA01H

Vehicle:	KIA Sorento AWD (02/2003 – 09/2009)
Towing Capacity:	2300kg
Fitting Kit:	2x 12 x 30mm <u>medium</u> thread bolts, spring & flat washers
	2x 12 x 40mm <u>medium</u> thread bolts, spring & flat washers
	1x 10 x 35mm fine thread bolt, spring & flat washer
	1x 10mm <u>thin</u> tapped plate on short wire
	2x 'D' Shackles
	2x Towbar Rating Labels

1.	Remove spare wheel.
2.	Mount tow hitch to existing holes in side of rear chassis using 12mm (medium) bolts supplied complete with spring & flat washers. Tighten.
3.	Drill (10mm) hole via centre support, fit tapped plate on wire into centre cross member via closest hole.
4.	Align tapped plate with drilled hole, fit 10mm bolt complete with spring & flat washer. Tighten.
5.	Check all bolts for tightness.
6.	Refit spare wheel.
7.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.