

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642

KIA4 FITTING INSTRUCTIONS
KIA RIO 4 DOOR HATCH

REMOVE REAR TAIL LIGHTS.
REMOVE REAR BUMPER BAR.
REMOVE SPARE WHEEL.
MOUNT TOWBAR TO CENTRE TIE DOWN USING 16mm BOLT SUPPLIED
COMPLETE WITH PLATE & SPRING WASHER. TIGHTEN.
DRILL (10mm) TWO HOLES VIA TOWBAR UNDER CAR INTO SPARE WHEEL
CARRYING AREA, OPEN TOP HOLES THEN FIT BOLTS TO PLATES THEN CRUSH
TUBES & FIT TO DRILLED HOLES, FIT SPRING WASHERS & NUTS – TIGHTEN.
DRILL (10mm) REMAINING TWO HOLES VIA TOWBAR UPRIGHT INTO BOOT
AREA, FIT 1/14 x 3/8 BOLTS SUPPLIED, FIT BOOT PLATE, SPRING WASHERS THEN
NUTS – TIGHTEN.
REFIT REAR BUMPER BAR.
REFIT TAIL LIGHTS.
REFIT SPARE WHEEL.

FITTING KIT:

1 – 16 x 45mm BOLT, SPRING WASHER & CROPPED PLATE
2 – 11/4 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS
2 – 21/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS
2 – 3/4 x 1/2 CRUSH TUBES
1 – BOOT PLATE
2 - 10mm HOLE PLATES
1 – DEE SHACKLE