

Fitting Instructions: LDV02H

Vehicle: V90 CAB CHASSIS

Towing Capacity: 2800 / 280Kg

Fitting Kit: 8 – 12 x 40mm Bolts, Flange Nuts & Flat washers

2 – 3 ½ x ½” Bolts, Nuts, Star and Flat washers

2 – 60mm ½” Clearance Crush tubes

4 – 10mm square spacer blocks with 14mm hole

2 – Dee Shackles

***ECM REQUIRED.**

1.	Remove (6) rear chassis bolts. 3 either side.
2.	Mount tow hitch using 2 x 12 x 40mm bolts supplied, add 3 ½ x ½” bolts to remaining vacant holes (complete with crush tubes & flat washers)
3.	Remove forward most bolts (2 either side) to fit support brace arms. Fit spacer blocks to inner side of chassis (2 either side) then support brace arms. Refit bolts removed.
4.	Fit 4 x 12 x 40mm Bolts to rear of support brace arms & main part of hitch. Once aligned – Tighten all bolts
5.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.