

## Fitting Instructions:

**LEX02H**

**Vehicle:** LEXUS RX350 WAGON 01/2023 - ON

**Towing Capacity:** 1500 / 150 Kg's

**Fitting Kit:**

- 5x M12 x 40mm Flange bolts
- 1x 1½ x 3/8 bolt on wire (no flat washer) Nut star & F/W.
- 2x D shackles
- 2x Towbar Rating Labels

### **ECM Required to wire this vehicle**

1.	Remove Drivers side tie down bracket & discard.
2.	Mount Tow Hitch to original holes in side of chassis rails using 12mm bolts supplied with kit. Do not tighten at this stage.
3.	Mount 12mm bolt to driver's side base of chassis via towbar tag. Do not tighten at this stage.
4.	Fit 3/8 bolt on wire into chassis rail passenger side via the existing hole from factory, fit flat & star washer then nut on outside of chassis rails.
5.	Tighten all bolts.
6.	Apply Towbar Rating Labels to driver's side door sill and non-removable part of the towbar.