

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03)9752 2642**

**MAZ38 FITTING INSTRUCTIONS:
E SERIES CAB CHASSIS.**

MOUNT TOWBAR TO VEHICLE SIDE OF REAR SUB FRAME USING ½" BOLTS SUPPLIED. TIGHTEN.
DRILL (10mm) HOLES VIA TOWBAR , FIT PLATES WITH BOLTS SUPPLIED AND TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

2 – 12 x 40mm BOLTS, NUTS, SPRING & FLAT WASHERS.
4 – 11/4 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.
4 – PLATES
1 – DEE SHACKLE.