

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2968**

**MAZ43 FITTING INSTRUCTIONS:
E SERIES S/W/B VAN 84 -**

MOUNT TOWBAR USING ½” BOLTS COMPLETE WITH CRUSH TUBES & PLATES SUPPLIED THROUGH ORIGINAL HOLES (ONE EITHER SIDE) IN REAR CHASSIS. FIT WASHERS & NUTS – TIGHTEN.
DRILL (1/2”) REMAINING TWO HOLES (ONE EITHER SIDE) VIA TOWBAR THROUGH CHASSIS INTO CARGO AREA, OPEN TOP HOLES TO ACCEPT CRUSH TUBES SUPPLIED, FIT TUBES COMPLETE WITH ½” BOLTS & PLATES – THEN WASHERS & NUTS - TIGHTEN.

FITTING KIT:

4 – 5/16 x ½ BOLTS, NUTS, STAR & FLAT WASHERS
4 – 105mm LONG CRUSH TUBES
4 - ½” HOLE PLATES
1 – DEE SHACKLE