

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**MAZ54 FITTING INSTRUCTIONS:
LASER/323 SEDAN 9/98 –**

REMOVE SPARE WHEEL.

MOUNT TOWBAR TO PASSENGER SIDE REAR TIE DOWN HOOK USING 16mm BOLT ON TOWBAR.

FEED TAPPED PLATES ON WIRE INTO SUB FRAME – DRIVERS SIDE, ALIGN WITH TOWBAR, FIT BOLTS WITH SPRING AND FLAT WASHERS - TIGHTEN.

FIT REMAINING TAPPED BOLT ON WIRE INTO SUB FRAME – PASSENGER SIDE, ALIGN WITH TOWBAR, FIT BOLT COMPLETE WITH SPRING AND FLAT WASHER – TIGHTEN.

DRILL (10mm) HOLE VIA SHORT TAIL THROUGH SPARE WHEEL CARRIER INTO BOOT, FIT BOLT AND PLATE SUPPLIED COMPLETE WITH NUT AND SPRING WASHER – TIGHTEN.

FITTING KIT:

3 – 10mm TAPPED PLATES ON WIRE

3 – 10 x 35mm BOLTS, SPRING AND FLAT WASHERS.

1 – 11/4 x 3/8 BOLT, NUT, SPRING AND FLAT WASHER.

1 – 10mm HOLE PLATE.

1 – DEE SHACKLE.