

Fitting Instructions: MAZ063

Vehicle:	Mazda 6 Wagon (02/2008 - 11/2012)
Towing Capacity:	1000kg
Fitting Kit:	4x M12 x 1.25 x 30 bolts on wire with Flange nuts 2x 1¼ x ¾ bolts, star / flat washers & nuts 2x M10 Hole Plates 1x 'D' shackle 2x Towbar Rating Labels

1.	Remove spare wheel.
2.	Remove tail lights & bumper.
3.	Remove rear most exhaust rubbers.
4.	Remove crash support panel. Retaining panel & nuts as this will be refitted at a later stage.
5.	Remove tape cover existing holes in underside of chassis adjacent to muffler (2 each side). Feed M12 x 30 bolts into chassis via these holes.
6.	Mount towbar to underside of chassis aligning with bolts inserted in previous step, fit flange nuts undercar (2 each side).
7.	Ensure towbar is central on car, tighten all bolts.
8.	Drill remaining two holes via towbar centre support. Feed 3/8 bolts via hole plates in boot area, undercar fit flat / star washers & nuts. Tighten bolts.
9.	Bumper cut required prior to refitting bumper. Locate centre of bumper, cut 45mm each side of centre & 70mm up from edge of bumper.
10.	Replace items removed in steps 1 - 4.
11.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.