

BTA Towbars

Australia's Towing Equipment Specialist



Fitting Instructions: MAZ064 / MAZ066

Vehicle: MAZDA 3/6 SEDAN/HATCH/WAGON 2014 - ON

Towing Capacity: MAZDA3 - 1200/120 MAZDA6 - 1600/120

Fitting Kit:

- 1x D shackle
- 2x Towbar Rating Labels

1.	Remove tail lights
2.	Remove bumper bar
3.	Remove crash support panel nuts then drop crash support panel away from back panel of vehicle.
4.	Mount towbar to vehicle back panel aligning with studs. Refit crash support panel with original nuts. Ensure towbar is central & tighten all nuts.
5.	Note: Some models may require a bumper cut prior to refitting bumper. Replace bumper bar and tail lights.
6.	NOTE: If vehicle has SMART CITY BRAKE SUPPORT – REVERSE (SCBS-R) AN ORIGINAL EQUIPMENT TRAILER HARNESS IS REQUIRED.
7.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.