



Fitting Instructions: MAZ067

Vehicle:	Mazda 6 Wagon (5/2019 – On)
Towing Capacity:	1600kg/120Kg
Fitting Kit:	4x 12 x 40 flange bolts on wire & Flange nuts
	1x 'D' Shackle
	2x Towbar Rating Labels

1.	Fit wire to bolts into chassis to existing holes via large hole (rear of car), these will align with towbar side-plate holes.
2.	Mount towbars to bolts fitted, fit nuts and tighten.
3.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.