

Fitting Instructions: MG01H

Vehicle: MG QS

Towing Capacity: 2000kg/100kg

Fitting Kit: 2 – 12 x 30mm fine bolts and flange nuts

2 – 12mm hole plates

2 – 6mm bolts, nuts & Flat washers

2 – Dee shackles

1.	Remove rear wheel arch plastic trims.
2.	Remove rear tail lights.
3.	Remove rear bumper bar.
4.	Remove and discard crash support panel.
5.	Mount tow hitch to rear panel using original nuts and bolts, tighten.
6.	Fit 12mm bolts (one either side) complete with plates supplied from under car bottom of chassis via original holes which align with tow hitch forward tags, fit flange nuts, tighten.
7.	Bumper cut required before refitting. Find centre of bumper bar, measure 40mm either side of centre, measure up from base/bottom of bumper bar 65mm, cut this rectangular section away from bumper.
8.	Wire ECM01 as per diagram provided.
9.	Refit rear bumper bar and tail lights.
10.	Refit wheel arch trims.
11.	Apply towbar rating labels to drivers side door sill and non removeable part of tow hitch.

Passenger side
Purple – L/H indicator
Purple/white – Taillight



Drivers side
Earth to body



Drivers side
Orange/Red – Right indicator
Blue/Red - Brake

