



Fitting Instructions: MHD01H

Vehicle: Mahindra Pik – Up Ute (09/2017 – ON)

Towing Capacity: 2500KGS / 250KGS

Fitting Kit:

- 4x 10 x 1.75 x 45mm **Course** bolts, flat & star washers
- 2x D - shackles
- 2x Towbar Rating Labels

1.	Remove original centre bumper support bolts & discard.
2.	Mount towbar to underside of bumper using M10 x 45 Course Bolt, Star & Flat washers.
3.	Tighten all bolts
4.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.