

## Fitting Instructions: MITS013H

**Vehicle:** Mitsubishi Outlander 4WD Wagon (11/06 – 11/12)

**Towing Capacity:** 1600kg

**Fitting Kit:**

6x	M10 x 1.25 x 35, star & flat washers
1x	½ x 4 bolt, star & flat washer, nut
1x	M12 hole plate (3 x 2)
1x	Spacer Tube M12 hole (50 x 50 x 100)
2x	'D' shackles
2x	Towbar Rating Labels

1.	Undercar remove exhaust rubbers (3) allowing muffler to drop clear of car.
2.	Mount towbar to underside of chassis using M10 x 1.25 x 35 bolts, star & flat washers (3 each side). Do not tighten at this stage.
3.	Feed ½ x 4 bolt via M12 hole plate, tie down hook, spacer tube aligning with remaining hole in towbar. Fit flat / star washer & nut. Do not tighten at this stage.
4.	Check hitch box is located centrally on bumper and tighten.
5.	Tighten all bolts on underside of chassis. Tighten bolt through tie down hook.
6.	Replace exhaust rubbers.
7.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.