

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

MITS6H FITTING INSTRUCTIONS
MITSUBISHI OUTLANDER WAGON

REMOVE REAR SHIPPING HOOKS AND DISCARD.
REMOVE REAR SECTION OF MUFFLER FROM RUBBER HANGERS.
MOUNT TOW HITCH TO EXISTING HOLES IN REAR CHASSIS USING 10mm
BOLTS SUPPLIED, COMPLETE WITH SPRING AND FLAT WASHERS.
TIGHTEN ALL BOLTS
REFIT REAR MUFFLER.

FITTING KIT

6 – 10 x 35 FINE THREAD BOLTS, SPRING & FLAT WASHERS
2 - DEE SHACKLES