

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2968**

**NIS2H FITTING INSTRUCTIONS**  
**NAVARA UTE / CAB CHASSIS**

MOUNT TOWBAR TO REAR SUB FRAME USING 6 – 12 x 40mm BOLTS SUPPLIED (VIA EXISTING HOLES) FIT COMPLETE WITH FLAT, SPRING WASHERS AND NUTS – TIGHTEN.

DRILL REMAINING HOLES VIA TOW HITCH THROUGH BOTTOM OF SUB FRAME, FIT 12mm BOLTS SUPPLIED COMPLETE WITH PLATES THEN SPRING WASHERS AND NUTS – TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS.

**FITTING KIT:**

10 – 12 x 40mm BOLTS, NUTS, SPRING & FLAT WASHERS

4 – PLATES 12mm HOLE.

2 – DEE SHACKLES