

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2968**

ACN004 883 336

NIS4H FITTING INSTRUCTIONS:
TERRANO IMPORT

MOUNT TOWHITCH TO REAR TIE DOWNS USING 16mm BOLTS SUPPLIED COMPLETE WITH SPRING & FLAT WASHERS. TIGHTEN.
DRILL (12mm) HOLES (2) VIA TOW HITCH SIDE ARMS THROUGH CHASSIS, FIT BOLTS SUPPLIED COMPLETE WITH SPRING , FLAT WASHERS, THEN NUTS, TIGHTEN.

FITTING KIT:

2 – 12 x 40mm BOLTS, NUTS, SPRING & FLAT WASHERS.
2 – 12mm HOLE PLATES.
2 – DEE SHACKLES.