

BTA Towbars

Australia's Towing Equipment Specialist



Fitting Instructions: **POR01H**

Vehicle: PORCHE CAYENNE (2019 - ON)

Towing Capacity: 3500kg / 350kg

Fitting Kit: 2x D shackles

 2x Towbar Rating Labels

ECM01/ECM02 Required

1.	Remove tail lights
2.	Remove rear bumper
3.	Remove & discard Crash Support Panel retaining mounting hardware
4.	Mount towbar to rear of car using bolts removed in previous step
5.	Ensure towbar is central & tighten all bolts
6.	Remove Tailgate sensor wire prior to bumper cut.
7.	Note: Bumper cut required. find centre of bumper mark 40mm either side, mark 180mm up from <u>base/bottom</u> edge of bumper. Cut this section out.
8.	Refit tailgate sensor wire.
9.	Refit items removed in steps 1 - 2
10.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.