



Towbar Fitting Instructions
To Suit MITSUBISHI TRITON 2WD `87-10/96
MK SERIES 11/96 – 06/06
(DOES NOT FIT WITH BUMPER)
Part Number QTCL372
Rating 1500Kg

1. Ensure all hardware items have been included.
2. Using two holes in chassis each side near spring hangers.
3. Mark centres and drill 4x13mm holes through second layer of chassis.
4. Fit 4 bolts on wire from end of chassis into holes just drilled.
5. Remove two bottom bolts, one each side, holding step bumper to chassis.
6. Fit spacer plate on bolt and refit.
7. Hold towbar up in position and fit 4 nuts to bolts on wire and tighten.
8. Using two remaining holes as guides drill up through chassis.
9. Fit tapped plates and bolts.
10. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.

TRAILBOSS

Towbar Fitting Instructions
To Suit MITSUBISHI TRITON 2WD '87-10/96
MK SERIES 11/96 – 06/06
(DOES NOT FIT WITH BUMPER)
Part Number QTCL372
Rating 1500Kg

