

TRAILBOSS

Towbar Fitting Instructions To Suit JEEP CHEROKEE K.J SERIES Part Number QTJP6 Rating 2250Kg

1. Ensure all hardware items have been included.
2. Remove and discard shipping hook.
3. Lift towbar up into position, aligning holes in towbar side plates with captive nuts in vehicle sub-frame, fit bolts, spring washers and flat washers as per diagram.
4. Tighten all bolts to torque listing.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

