



Fitting Instructions: SSY07H

Vehicle: Ssangyong Musso EV Utility (2025 – on)

Towing Capacity: Updated 2026 AWD model - 2300kg/230kg

2WD models and AWD prior to 2026 update – 1800Kg/180Kg

Fitting Kit: 20x 12 x 1.25 x 40mm Flange bolts.

8x 12mm Flange nuts

2x 'D' shackles

2x Towbar Rating Labels

1.	Mount side arms to chassis using flange bolts supplied (6 bolts either side), do not tighten at this stage.
2.	Mount cross pipe using remaining flange bolts (4 either side) with nuts.
3.	Tighten side arm bolts then cross pipe bolts.
4.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.