

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

SUB10 / SUB11 FITTING INSTRUCTIONS
SUBARU LIBERTY OUTBACK WAGON 1998 - ON
TOWING CAPACITY 1400KG

MOUNT TOWBAR USING (16mm) BOLTS SUPPLIED VIA TIE DOWN HOOKS AT REAR OF VEHICLE & TIGHTEN.

FIT (12mm) BOLT SUPPLIED VIA TOWBAR SIDE ARM TO EXISTING HOLE IN SUBFRAME (SUB10 ONLY) - DRIVERS SIDE - TIGHTEN.

DRILL (10mm) HOLE VIA TOWBAR - PASSENGER & DRIVERS' SIDE, FEED TAPPED PLATE INTO SUBFRAME. FIT BOLT & SPRING WASHER & TIGHTEN. REMOVE SPARE WHEEL.

DRILL (10mm) HOLES VIA TOWBAR TAIL INTO SPARE WHEEL AREA. FIT BOLTS TO PLATES & FIT VIA HOLES DRILLED, FIT NUTS & SPRING WASHERS - TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

- 2 - 16mm x 45mm BOLTS, SPRING WASHERS, PLATES & NUTS (ON TOWBAR).
- 2 - 1.1/2" x 3/8" BOLTS, NUTS & SPRING WASHERS.
- 1 - 12mm x 30mm BOLT, SPRING & FLAT WASHER.
- 2 - 3" x 1.1/2" x 3/8" HOLE PLATE.
- 1 - D SHACKLE.
- 2 - 10mm TAPPED PLATE ON WIRE
- 2 - 10mm BOLT, SPRING & FLAT WASHER