

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**SUB15 FITTING INSTRUCTIONS
2008 IMPREZA HATCH**

REMOVE TAIL LIGHTS.
REMOVE REAR BUMPER.
REMOVE AND DISCARD CRASH SUPPORT PANEL.
REMOVE RUBBER GROMMITS FROM BOTTOM OF CHASSIS RAIL TO EXPOSE ORIGINAL HOLES.
FEED TOWBAR SIDE ARMS INTO CHASSIS RAILS, (CHASSIS OPENING WILL NEED EXPANDING TO ALLOW SIDE ARMS TO FIT) THEN ALIGN WITH EXPOSED CHASSIS HOLES.
FEED 4 X WIRE TO BOLTS INTO CHASSIS AND FIT VIA TOWBAR AND ALIGNED HOLES, FIT PLATES SUPPLIED, COMPLETE WITH SPRING WASHERS AND NUTS – TIGHTEN.
FIND CENTRE OF BUMPER AND MARK 45MM EITHER SIDE OF CENTRE AND 40MM UP FROM BASE OF BUMPER, THEN CUT OUT.
REFIT BUMPER AND TAIL LIGHTS.

FITTING KIT:

4 – 1 ½ x 3/8 WIRE TO BOLTS, NUTS, SPRING AND FLAT WASHERS
4 – 3/8 HOLE PLATES
1 – DEE SHACKLE.