

Fitting Instructions: SUB016 & SUB020

Vehicle: Subaru Outback Wagon MY10 (09/09 - 01/15)

Subaru Liberty Sedan MY10 (09/09 - 01/15)

Towing Capacity: 1500kg (Outback) / 1250kg (Liberty)

Fitting Kit:

- 8x 10mm flat & star washers
- 2x 10mm hole plates
- 2x $\frac{3}{8}$ " x $1\frac{1}{2}$ " bolts, nuts, star & flat washers
- 1x 'D' shackle
- 2x Towbar Rating Labels

1.	Remove spare wheel.
2.	Remove tail lights.
3.	Remove rear bumper.
4.	Remove crash support panel.
5.	Bend bumper centre support tag up against back panel.
6.	Mount towbar with crash support panel to rear studs (4 each side) using flat / star washer & nuts removed in step 3.
7.	Centralise towbar and tighten.
8.	Drill via towbar 2 holes undercar (11mm), fit plates with bolts into spare wheel area, fit nuts with flat and star washers to underside of car. Tighten.
9.	Replace spare wheel.
10.	Bumper cut required prior to refitting bumper. Note: Bumper cut varies between models, locate centre of bumper and initially cut 45mm either side of centre for a distance of 60mm from base of bumper. This distance up from base of bumper may need to be increased up to 110mm on some models.
11.	Refit bumper.
12.	Refit tail lights.
13.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.