

Fitting Instructions



SKU

PRODUCT

T2D462

**TAG Standard Duty Towbar
to suit Nissan X-TRAIL
(10/2001 - 09/2007)**



Scan for latest
version of these
instructions

SPECIFICATIONS

- Towbar Class: Standard Duty
- Towing Capacity: 1200kg

IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. Remove bumper.
 - 1.1. Lift Tailgate.
 - 1.2. Remove 2 bolts from behind tailgate holding bumper.
 - 1.3. Remove 4 screws from each wheel arch, 1 at the top, 1 from underneath and 2 from behind splash guard up into quarter panel.
 - 1.4. Remove plastic cover from underneath and discard.
 - 1.5. Remove 2 scrivenets from bottom of bumper.
2. Remove crash cans.
3. Remove spare wheel and spare wheel cover from inside of boot.
4. Fit towbar to vehicle by the bottom of the chassis rail on driver's side and the inner-side of the chassis rail on the passenger side.

Towbar Fitting Instructions



5. Fit 2x M12 bolts on wire with square plates through rear holes in chassis rail to line up with rear holes in towbar. Fit nuts & washers supplied.
6. Fit 2x M12 bolts on wire with square plates through holes in chassis rail to line up with forward holes in towbar. Fit nuts & washers.
7. Using the towbar as a guide, drill 2x 11mm holes into wheel well.
8. Fit 2x M10 bolts & plates through drilled holes and fit nuts & washers from underneath.
9. Tighten all bolts to torque listing below.
10. Re fit bumper.
11. Re fit spare wheel and cover.
12. Fit tongue with bolts supplied.
13. Fit door sticker supplied to door.

Torque table for bolt tightening

Metric GRADE 8.8
M6 – 9.5 Nm
M8 – 21.7 Nm
M10 – 43.4 Nm
M12 – 77.3 Nm
M16 – 189.8 Nm

TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au