

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**TOY11H FITTING INSTRUCTIONS:
HILUX WITH REAR STEP.**

REMOVE REAR BUMPER BAR, THEN REMOVE BUMPER FROM BUMPER HOLDING BRACKETS.

REFIT BRACKETS INTO SUB FRAME THEN MOUNT TOWHITCH TO VEHICLES EXISTING HOLES USING 4 - 12mm BOLTS SUPPLIED, COMPLETE WITH SPRING & FLAT WASHERS. TIGHTEN. (ON LATE MODELS BUMPER BRACKETS FIT TO OUT SIDE OF CHASSIS WITH TOW HITCH, THEN REFIT BUMPER TO BRACKETS).

DRILL (10mm) HOLES VIA BOTTOM TOWBAR BRACKET THROUGH BASE OF REAR SUB FRAME, FIT 3/8 BOLTS SUPPLIED WITH PLATES, SPRING & FLAT WASHERS TIGHTEN.

REFIT BUMPER BAR.

NOTE:

ON CERTAIN MODELS, PLATES SUPPLIED ARE TO BE FITTED BETWEEN BUMPER BRACKETS AND SUB FRAME (THUS ACTING AS SPACERS), THEN HOLES ARE TO BE DRILLED THROUGH BUMPER BRACKETS, FIT BOLTS SUPPLIED WITH SPRING WASHERS & NUTS – TIGHTEN.

FITTING KIT:

4 – 12 x 40mm BOLTS, NUTS, SPRING & FLAT WASHERS.

4 – 11/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS

4 – 10mm OFFSET HOLE PLATES

2 – DEE SHACKLES.