

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2968**

**TOY12H FITTING KIT
RAV4 WAGON 2000 –**

REMOVE REAR TIE DOWNS.
MOUNT TOWHITCH TO REAR SUBFRAME USING 12mm BOLTS COMPLETE
WITH SPRING & FLAT WASHERS SUPPLIED, TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

4 – 12 x 40mm BOLTS, SPRING & FLAT WASHERS.
2 – DEE SHACKLES.